

EASY STEP-BY-STEP WALLPAPER INSTALLATION

ConcreteWall™

PLEASE NOTE!

A. FOR SAFETY, WE HAVE ADDED OVERAGE IN BOTH THE TOTAL WIDTH AND THE LENGTH OF EACH TILE/SHEET.

B. FOR ALL NEW AND REFINISHED WALL SURFACES, A WATER-BASED WALLPAPER PRIMER SHOULD BE APPLIED. TRY TO TINT THE PRIMER TO MATCH THE COLOR OF THE WALLPAPER.

C. WE RECOMMEND TO USE OF A GOOD QUALITY HEAVY DUTY «CLEAR» VINYL ADHESIVE AS MADE BY ZINSSER AND ROMAN. DO NOT DILUTE ADHESIVE.

D. ACCEPTABLE HANGING SURFACES MUST BE CLEAN, SMOOTH, DRY AND STRUCTURALLY INTACT.

E. REMEMBER TO INSTALL THE TILES BUTT JOINT!

